

Using Do Not Disturb

You may temporarily stop your phone from ringing.

When using the menu:

- Arrow to and select “Do not disturb on?” or press *97

To deactivate

- Arrow to and select “Do not disturb off?” or press *97

When using a programmed key:

- Press the “DND” key.

To deactivate

- Press the “DND” key.



Nix Communications Group Ltd

Tel: 0844 318 5000

Fax: 0844 318 5555



Opening Hours:

Monday - Thursday 09:00 -
17:30

Friday 09:00 - 16:30